

Spare Tire Carrier for Polaris RZR1000 / RZR XP



ZP-YJ-030503-0950

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.


IMPORTANT

The Spare Tire Carrier Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

1. Assemble parts 1,2 and 3 with four M8*50 inner hexagon screws, four M8 locknuts.



Notice: The larger screw holes of the pipe 2 face up, the smaller screw holes of the pipe 2 face down.



2. Fix the Spare Tire Carrier on the rear frame with eight M8*35 inner hexagon screws.

