LED Taillights for Polaris RZR XP 1000 2024



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This LED Taillights *Kit* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product picture and accessories



1. First distinguish the left and right sides of the taillights, then unscrew the nuts of the rear housing of the new taillight, remove the original taillight, and finally connect the wiring harness plug-in of the original vehicle to the new taillight. As the picture shows:







2. Insert the set screws on the rear housing of the new taillight into the positioning holes of the original vehicle, and finally re-tighten the nuts from the inside. (The taillight on the other side is replaced and installed in the same way). As the picture shows:

LED Taillights for Polaris RZR XP 1000 2024
















3. Installation finished.