

LED Headlights for Polaris RZR XP 1000/XP 4 1000 2024+



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

IMPORTANT

This *LED Headlights Kit* is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.



INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.





Product picture and accessories



1. First open the original hood, and then remove the front trim plate. As the picture shows:




LED Headlights for Polaris RZR XP 1000/XP 4 1000 2024+



2. Disconnect the harness plug-ins of the original headlight, remove the original headlight and replace it with a new headlight, and use the original screws to fix it, and then connect the original wiring harness with the new headlight (the other side of the headlight is replaced and installed in the same way), and then finally install the removed parts back in place. As shown in the picture:

Note: the new headlights have a steering function, you can choose to purchase a steering strobe device and connect the wire by yourself.



3. Installation finished.

LED Headlights for Polaris RZR XP 1000/XP 4 1000 2024+



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.