

Gas Tank Cover for Yamaha Raptor 700



ZP-YJ-031103-016

BEFORE YOU BEGIN


Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

The Gas Tank Cover is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

Note: Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.

Product and accessories picture:



1. First, remove the seat cushion of the original vehicle and the screws that secure the radiator grille decorative frame. Then, remove the snap fasteners that secure the gas tank cover and unscrew the fuel tank cap. As shown in picture:



Gas Tank Cover for Yamaha Raptor 700



ZP-YJ-031103-016



2. Remove the original gas tank cover and replace it with a new one. Use the original vehicle buckle to fix it, then screw back the fuel tank cap and reinstall the decorative frame and seat cushion. As shown in picture:



3. Installation completed!



Note: Please refer to the installation video in the Amazon listing before your installation, or contact the seller for the installation video.