

# REAR DOOR PANELS FOR CAN-AM MAVERICK X3 MAX

ZP-YJ-030603-018




## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference.

## IMPORTANT



This DOOR PANELS KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris.

The installation guide video is available in the listing, please refer to it before you installation.



## INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission into "PARK". Turn key to "OFF" position and remove from vehicle.
2. Remove and discard the screw and washer fixing the rear left lower door cover.




3. Remove and discard the two (2) screws, two (2) nuts and two (2) washers fixing the rear left lower door cover in order to remove it.


4. Open LH rear door and drill a hole of 30 mm (1-3/16 in) using a step drill where specified below.

# REAR DOOR PANELS FOR CAN-AM MAVERICK X3 MAX

ZP-YJ-030603-018




5. Insert the screw [P5.1] and the support washer [P5.3] then pass the screw through the slotted hole.



1. M6 x 40 hexagonal screws

2. Panel Nuts


8. Fix the LH door assembly to the door of the vehicle by using two (2) M6 elastic nuts and two (2) support washers. Do not tighten.



1. M6 x 80 Hexagonal Screw

2. Support Washer

6. Insert one (1) M6x50 screw and one (1) M6x80 screw with two (2) support washer in their respected holes.




1. Rear LH Door Assembly

2. Elastic Nuts

3. Support Washers

9. Install the screw and tighten it.




1. M6 x 80 Hexagonal Screw

2. M6 x 50 Hexagonal Screw

3. Support Washer

7. Fix the Rear LH Door Structure [P3] to Rear LH Door Panel [P1] using three (3) screws and three (3) panel nuts. Do not tighten. The frame must be able to move a little. Install a panel nut on the upper support.



1. M6 x 25 Hexagonal Screw